



# FREEDOMLINK+ PG324 USER MANUAL



[www.freedomlinkplus.com](http://www.freedomlinkplus.com)

# Thank you for your purchase!


## Before Getting Started

1. Make sure you have a good 4G signal
2. Make sure the SIM Card is securely inserted.
3. This SIM card can not be used in any other device and will cause the SIM card to be locked.
4. Charge the battery 12-14 hours for the first initial charge.

# Items Included with Your Purchase

1. Li-Ion Battery
2. Wrist Strap
3. Antenna
4. SIM Card
5. Belt Clip
6. 1 Year Airtime
7. 1 Year Warranty

Volume Knob



← Antenna



Push-To-Talk  
Button



← SIM Slot



Radio Status



← Charging Port



# Common Functions

## **Group Call**

Just like a regular two way radio, when you speak in a group, all other people in this group will receive you call.

## **Single Call**

When you enter the single call mode, you can choose the users of the current group online and let them enter the single channel mode with you. When one of you quits the single call mode, the two parties will exit the single call mode at the same time and return to the original group.

# Programming

Please contact us at [info@freedomlinkplus.com](mailto:info@freedomlinkplus.com) for any programming changes you require. Programming changes can be made over the air.

Examples of programming changes:

- Names (Between 2-11 Characters)
- Groups

# Warranty

Thank you for your interest in the products and services of FreedomLINK+. This Limited Warranty applies to physical goods, and only for physical goods, purchased from FreedomLINK+ (the "Physical Goods").

## **What does this limited warranty cover?**

This Limited Warranty covers any defects in material or workmanship under normal use during the Warranty Period. During the Warranty Period, FreedomLINK+ will repair or replace, at no charge, products or parts of a product that proves defective because of improper material or workmanship, under normal use and maintenance.

## **What will we do to correct problems?**

FreedomLINK+ will either repair or replace the Product at no charge, using new or refurbished replacement parts.

## **How long does the coverage last?**

The Warranty Period for Physical Goods purchased from FreedomLINK+ is 1 year from the date of purchase. A replacement Physical Good or part assumes the remaining warranty of the original Physical Good or 1 year from the date of replacement or repair, whichever is longer.

## **What does this limited warranty not cover?**

This Limited Warranty does not cover any problem that is caused by: ● conditions, malfunctions, or damage not resulting from defects in material or workmanship

## **What do you have to do?**

To obtain warranty service, you must first contact us to determine the problem and the most appropriate solution for you.



405 N. Hastings Pl.  
Eau Claire, WI 54703  
(715) 832-6763

[info@freedomlinkplus.com](mailto:info@freedomlinkplus.com)  
[www.freedomlinkplus.com](http://www.freedomlinkplus.com)